



- NOTES:
1. LHR SHOWN; RHR OPPOSITE.
  2. DIMENSIONS SHOWN IN INCHES AND (mm).
  3. REF. DEVICE TEMPLATE FOR "X-X" CENTERLINE.
  4.  $\varnothing$  3/16" (5mm) PILOT HOLE TO BE DRILLED AT INSTALLATION.

HDG. \_\_\_\_\_ DR. \_\_\_\_\_

**RESPONSIBILITY**  
 Door and Frame Manufacturers are responsible for providing adequate construction or reinforcements for proper installation of hardware shown. All architectural builders hardware must be installed on properly reinforced doors and frames regardless of the type, material or method of construction.

TEMPLATE  
 WOOD DOOR  
 03P/03PN  
 CYLINDER PULL TRIM

**DETEX**  
CORPORATION

DO NOT SCALE DRAWING

DATE 11/16/07	TEMPLATE NUMBER T1078
---------------	-----------------------