



- NOTES:
1. LHR SHOWN; RHR OPPOSITE.
 2. DIMENSIONS SHOWN IN INCHES AND (mm)
 3. USE 98 STRIKE

HDG. _____ DR. _____

RESPONSIBILITY

Door and Frame Manufacturers are responsible for providing adequate construction or reinforcements for proper installation of hardware shown. All architectural builders hardware must be installed on properly reinforced doors and frames regardless of the type, material or method of construction.

TEMPLATE
ALUMINUM DOOR
1001 & F1001 SERIES
RIM EXIT DEVICE
BP-5 MOUNTING PLATE

DETEX
CORPORATION

DO NOT SCALE DRAWING

DATE 6/21/05	TEMPLATE NUMBER T1107
-----------------	--------------------------