



- NOTES:
1. LHR SHOWN; RHR OPPOSITE.
 2. DIMENSIONS SHOWN IN INCHES AND (mm).
 3. REF. DEVICE TEMPLATE FOR "X-X" CENTERLINE.
 4. SEE T2002 FOR DEVICE SIDE PREP.

HDG. _____ DR. _____

RESPONSIBILITY
 Door and Frame Manufacturers are responsible for providing adequate construction or reinforcements for proper installation of hardware shown. All architectural builders hardware must be installed on properly reinforced doors and frames regardless of the type, material or method of construction.

TEMPLATE
 WOOD DOOR
 02DM/02DMT/02DMU
 WIDE LEVER TRIM BP-9
 MOUNTING PLATE

DETEX

DO NOT SCALE DRAWING

DATE 7-23-10 TEMPLATE NUMBER T1176